

MCDB 感應開關安裝 $\phi 10\sim\phi 32$


雙軸倍力滑台氣壓缸



感應開關安裝：

感應開關：RCD


設變後



感應開關安裝：

感應開關：RCB

設變前



附磁型安裝感應開關：

代號 內徑	A	B	C	D	E	F
10	61	37	13	16	22	5
16	75	44	13	16	22	5
20	86	49.5	13	16	22	5
25	92	52.5	13	16	22	5
32	126	69.5	13	16	22	5

